


BB5 King Applet update and activate manual (version 1)


1. For users with BB5 Box

- Start BB5 Box software version v0.0.5.0.
- You can find v0.0.5.0 BB5 box software to download from here http://www.bb5king.com/BB5_v050_EXE_Only.zip
- Follow instructions form this screenshot to write BB5 King applet on card:



After applet is written correctly on card, you have to activate this. To be able to activate applet, your BB5 Box serial number need to be in our server database. To add your serial number in our database please contact your reseller.


Follow instructions form this screenshot to activate BB5 King applet:



2. For users with JAF P-KEY

Start latest version of JAF software.

Follow instructions form this screenshoot to write BB5 King applet on PKEY smartcard:



After applet is written correctly on card, you have to activate this. To be able to activate applet, your PKEY serial number need to be in our server database. To add your serial number in our database please contact your reseller.

Activations for BB5 King applet written on PKEY need to be made with BB5 King Activator Software. You can download this from http://www.bb5king.com/BB5_King_Activator_V1.exe

Follow instructions form this screenshot to activate BB5 King applet:

